

KIDS WATCH QUICKSTART GUIDE


Do you have a « **Kids Watch** » by Annatel.family and want to start it up? Below are step by step instructions on how to do so:

1

Charge the watch for about 1 hour.

Turn it on by pressing the right side button for a few seconds.

Wait for a network connection. Then wait for 2 to 3 minutes before moving on to step 2.



2

Download and install the « **Find my Kids** » app from your smartphone, then launch it.



3

Following the introduction screens, choose « **connect a GPS-watch** » and press « **Continue** ».

Scan the QR code on the back of the watch (or manually enter the number at the bottom of the sticker) and confirm.

Enter the phone number of the watch (i.e. number of your « **Kids Watch** » mobile plan) and click « **Continue** ». Follow the instructions on the screen.

You will be able to change the default settings of the watch afterwards.



Congratulations! The entire family can now fully enjoy all the features of the « **Kids Watch » by annatel.Family**

Any questions? Contact us by :



Phone
*0555



WhatsApp RECOMMENDED
+972 55 500 6565



Email
support@annatel.us

